



BP 249 Z. I.
44158 ANCENIS CEDEX - FRANCE
TEL : 33 (0)2 40 09 10 11

YOUR DEALER

547378 EN (01 / 06 / 2006)

ACCESS PLATFORM

120 AETJ L

150 AETJ C

150 AETJ L

170 AETJ L

OPERATOR'S MANUAL



PREAMBLE

This instructions manual is designed to explain how to operate the machine and the maintenance required periodically for the machine to continue to operate in complete safety.

The platform has been designed and produced to enable you to work at high level in complete safety.

Before its delivery, MANITOU and the concessionaire have carefully inspected the platform so that you receive it in perfect operating condition.




1 - OPERATING AND SAFETY INSTRUCTIONS

2 - DESCRIPTION

3 - MAINTENANCE

4 - MAINTENANCE HANDBOOK

06/02/2006	1ST DATE OF ISSUE
01/06/2006	UP DATING (2-6 ; 2-7 ; 2-9 ; 3-9)





1 - OPERATING AND SAFETY INSTRUCTIONS





TABLE OF CONTENTS

<i>INSTRUCTIONS TO THE COMPANY MANAGER</i>	<i>1 - 4</i>
PREAMBLE	1 - 4
THE OPERATOR	1 - 4
THE PLATFORM	1 - 4
A - THE PLATFORM'S SUITABILITY FOR USE	1 - 4
B - ADAPTING THE PLATFORM TO THE USUAL ENVIRONMENTAL CONDITIONS	1 - 4
C - MODIFYING THE PLATFORM	1 - 5
THE INSTRUCTIONS	1 - 5
THE MAINTENANCE	1 - 5
<i>INSTRUCTIONS FOR THE OPERATOR</i>	<i>1 - 6</i>
PREAMBLE	1 - 6
GENERAL INSTRUCTIONS	1 - 6
A - OPERATOR'S MANUAL	1 - 6
B - AUTHORIZATION FOR USE IN FRANCE (or see current legislation in other countries).	1 - 6
C - MAINTENANCE	1 - 7
D - MODIFYING THE PLATFORM	1 - 7
E - PLATFORMAXLES	1 - 7
DRIVING INSTRUCTIONS	1 - 8
A - BEFORE STARTING THE PLATFORM	1 - 8
B - DRIVER'S OPERATING INSTRUCTIONS	1 - 8
C - ENVIRONMENT	1 - 8
D - VISIBILITY	1 - 9
E - STARTING THE PLATFORM	1 - 10
F - DRIVING THE PLATFORM	1 - 11
G - STOPPING THE PLATFORM	1 - 12
INSTRUCTIONS FOR WELDING AND BLOW TORCH WORK ON THE EXTERNAL STRUCTURE	1 - 13
A - WITH ELECTRICAL WELDING EQUIPMENT	1 - 13
B - WITH A BLOW TORCH	1 - 13
<i>PLATFORM MAINTENANCE INSTRUCTIONS</i>	<i>1 - 14</i>
GENERAL INSTRUCTIONS	1 - 14
MAINTENANCE	1 - 14
LUBRICANT AND FUEL LEVELS	1 - 14
LEVEL OF ELECTROLYTE IN THE BATTERY	1 - 14
HYDRAULIC	1 - 14
ELECTRICITY	1 - 15
WELDING ON THE ACCESS PLATFORM	1 - 15
WASHING THE PLATFORM	1 - 15
<i>IF THE PLATFORM IS NOT TO BE USED FOR A LONG TIME</i>	<i>1 - 16</i>
INTRODUCTION	1 - 16
PREPARING THE PLATFORM	1 - 16
PROTECTING THE I.C. ENGINE	1 - 16
CHARGING THE BATTERIES	1 - 17
PROTECTING THE PLATFORM	1 - 17
BRINGING THE PLATFORM BACK INTO SERVICE	1 - 17
<i>SAFETY DECALS</i>	<i>1 - 18</i>



INSTRUCTIONS TO THE COMPANY MANAGER

PREAMBLE

WHENEVER YOU SEE THIS SYMBOL IT MEANS :



WARNING ! BE CAREFUL ! YOUR SAFETY OR THE SAFETY OF THE PLATFORM IS AT RISK.

THE OPERATOR

- Only qualified, authorized personnel can use the platform. This authorization is given in writing by the appropriate person in the establishment with respect to the use of platform and must be carried permanently by the operator.



On the basis of experience, there are a number of possible situations in which operating the platform is contra-indicated. Such foreseeable abnormal uses, the main ones being listed below, are strictly forbidden.

- The foreseeable abnormal behaviour resulting from ordinary neglect, but does not result from any wish to put the machinery to any improper use.
- The reflex reactions of a person in the event of a malfunction, incident, fault, etc. during operation of the platform.
- Behaviour resulting from application of the "principle of least action" when performing a task.
- For certain machines, the foreseeable behaviour of such persons as : apprentices, teenagers, handicapped persons, trainees tempted to drive a platform, operator tempted to operate a truck to win a bet, in competition or for their own personal experience.

The person in charge of the equipment must take these criteria into account when assessing whether or not a person will make a suitable driver.



OBTAIN INFORMATION ON :

- How to behave when there is a fire.
- The location of the nearest first aid kit and fire extinguisher.
- The emergency telephone numbers for calling (the doctors, ambulance, hospital and fire brigade).

THE PLATFORM

A - THE PLATFORM'S SUITABILITY FOR USE

- MANITOU has ensured that this platform is suitable for use under the standard operating conditions defined in this operator's manual, with an overload test coefficient of 1,25 and an operational test coefficient of 1,1, as stipulated in standardised norm **EN 280** for **MPLP (Mobile Personnel Lifting Platforms)**.
- Before commissioning, the company manager must make sure that the platform is appropriate for the work to be done, and perform certain tests (in accordance with current legislation).

B - ADAPTATING THE PLATFORM TO THE USUAL ENVIRONMENTAL CONDITIONS

- In addition to series equipment mounted on your platform, many options are available, such as : flashing light, working headlight, etc.
Contact your dealer.
- Take into account climatic and atmospheric conditions of the site of utilisation.
 - . Protection against frost (see : 3 - MAINTENANCE : LUBRICANTS AND FUEL).
 - . Adaptation of lubricants (ask your dealer for information).
 - . I.C. engine filtration (see : 3 - MAINTENANCE : FILTERS CARTRIDGES AND BELTS).



For operation under average climatic conditions, i.e. : between -15 °C and + 35 °C, correct levels of lubricants in all the circuits are checked in production. For operation under more severe climatic conditions, before starting up, it is necessary to drain all the circuits, then ensure correct levels of lubricants using lubricants properly suited to the relevant ambient temperatures. It is the same for the cooling liquid.

- A platform operating in an area without fire extinguishing equipment must be equipped with an individual extinguisher. There are solutions, consult your dealer.



Your platform is designed for outdoor use under normal atmospheric conditions and indoor use in suitably aerated and ventilated premises. It is prohibited to use the platform in areas where there is a risk of fire or which are potentially explosive (e.g. Refineries, fuel or gas depots, stores of inflammable products...). For use in these areas, specific equipment is available (ask your dealer for information).

C - MODIFYING THE PLATFORM

- For your safety and that of others, you must not change the structure and settings of the various components used in your platform (hydraulic pressure, calibrating limiters, I.C. engine speed, addition of extra equipment, addition of counterweight, unapproved attachments, alarm systems, etc.) yourself. In this event, the manufacturer cannot be held responsible.

THE INSTRUCTIONS

- The operator's manual must always be in good condition and kept in the place provided on the platform and in the language used by the operator.
- You must necessarily replace the instructions manual, as well as any plates or stickers, if they are no longer legible or are missing or damaged.

THE MAINTENANCE

- Maintenance or repairs other than those detailed in part : 3 - MAINTENANCE must be carried out by qualified personnel (consult your dealer) and under the necessary safety conditions to maintain the health of the operator and any third party.



Your platform must be inspected periodically to ensure that it remains in compliance. The frequency of this inspection is defined by current legislation in the country in which the platform is used.



INSTRUCTIONS FOR THE OPERATOR

PREAMBLE

WHENEVER YOU SEE THIS SYMBOL IT MEANS :



WARNING ! BE CAREFUL ! YOUR SAFETY OR THE SAFETY OF THE PLATFORM IS AT RISK.



The risk of accident while using, servicing or repairing your platform can be restricted if you follow the safety instructions and safety measures detailed in these instruction.

- Only the operations and manoeuvres described in these operator's manual must be performed. The manufacturer cannot predict all possible risky situations. Consequently, the safety instructions given in the operator's manual and on the platform itself are not exhaustive.
- At any time, as an operator, you must envisage, within reason, the possible risk to yourself, to others or to the platform itself when you use it.



Failure to respect the safety and operating instructions, or the instructions for repairing or servicing your platform may lead to serious, even fatal accident.

GENERAL INSTRUCTIONS

A - OPERATOR'S MANUAL

- Carefully read and understand the operator's manual.
- The operator's manual must always be kept in the place provided for it on the platform and be written in the language used by the operator.
- Any operations or manoeuvres not described in the operator's manual must necessarily be forbidden right from the start.
- Follow the safety advice and the instructions on the platform.
- You must necessarily replace the operator's manual, as well as any plates or stickers, if they are no longer legible or are damaged.
- A second operator must necessarily be present on the ground as a safety measure when using the platform.
- Familiarise yourself with the platform on the terrain it has to travel over.
- The machine must also be used in accordance with good engineering practice.
- Do not use the platform if the wind speed is over 45 km/h. The platform's arms must not be subjected to a lateral force of more than 40 kg (platforms for indoor use must not be used outside the building).

B - AUTHORIZATION FOR USE IN FRANCE

(or see current legislation in other countries)

- Only qualified, authorized personnel may use the platform. This authorization is given in writing by the appropriate person in the company, in charge of using the platform, and must be permanently carried by the operator.
- The operator is not competent to authorise the driving of the platform by another person.



C - MAINTENANCE

- The operator must immediately advise his superior if his platform is not in good working order or does not comply with the safety notice.
- The operator is prohibited from carrying out any repairs or adjustments himself, unless he has been trained for this purpose. He must keep the platform properly cleaned if this is among his responsibilities.
- The operator must carry out daily maintenance (see : 3 - MAINTENANCE : A - DAILY OR EVERY 10 HOURS SERVICE).
- The operator must ensure tyres are adapted to the nature of the ground (see area of the contact surface of the tyres in the chapter : 2 - DESCRIPTION : CHARACTERISTICS). There are optional solutions, consult your dealer.



Do not use the platform if the tyres are damaged or excessively worn, because this could put your own safety or that of others at risk, or cause damage to the platform itself.



- In the case of electric platforms, the operator must ensure that:
 - The batteries are not replaced with lighter ones (compromising stability).
 - Safety goggles are always worn when charging the batteries.
 - The batteries are not charged in an explosive environment.
 - There is no smoking and no naked flame directed towards the batteries when they are being handled (during removal, re-installation and checking the levels) .

D - MODIFYING THE PLATFORM

- For your safety and that of others, you must not change the structure and settings of the various components used in your platform yourself:
 - hydraulic pressure,
 - calibrating limiters,
 - I.C. engine speed,
 - addition of extra equipment,
 - addition of counterweight,,
 - unapproved attachments,
 - alarm systems, etc...

In this event, the manufacturer cannot be held responsible.

E - PLATFORM AXLES

- Standard axles:



The chassis is rigid, so the platform can have a ground reach on only three wheels.

- Oscillating axle (if the option is available):



An oscillating axle enables the platform, when in transport position, to have a ground reach on four wheels. When moving in working position over uneven terrain, the oscillating axle is locked (the chassis is rigid) so the platform can have a ground reach on only three wheels.



DRIVING INSTRUCTIONS

A - BEFORE STARTING THE PLATFORM

- Ensure that the intermediate rail is fully in the locked position before operating the platform from the basket.
- If the platform is new, see the Chapter : BEFORE STARTING THE PLATFORM FOR THE FIRST TIME in Section : 1 - SAFETY ADVICE AND INSTRUCTIONS.
- Carry out daily maintenance (see : 3 - MAINTENANCE : A - DAILY OR EVERY 10 HOURS SERVICE).
- Before starting the platform, check the levels :

• IC PLATFORMS :		• ELECTRIC PLATFORMS :
• IC engine oil		• Hydraulic reservoir oil.
• Hydraulic reservoir oil.		• Battery charge level.
• Fuel.		
• Coolant.		
- Whatever his experience, the operator is advised to familiarize himself with the position and operation of all the controls and instruments before operating the platform.
- The platform must be in transport position (arms fully folded or scissors in the low position) before you climb onto the platform.
- Make sure the horn works.

B - DRIVER'S OPERATING INSTRUCTIONS

- Wear suitable clothing for driving the platform, do not wear baggy clothes.
- Make sure you have the appropriate protective equipment for the job to be done.
- Prolonged exposure to high noise levels may cause hearing problems. It is recommended to wear ear muffs to protect against excessive noise.
- Always pay attention when using the platform. Do not listen to the radio or music using headphones or earphones
- For increased comfort, adopt the correct position in the driver's cab.
- The operator must always be in his normal position in the driver's seat : extending arms or legs (or, in general, any part of the body), outside the basket is forbidden.
- Safety helmets must be worn.
- MANITOU recommends a safety harness in the operator's size be provided when the platform is in use (for the harness attachment in the basket , see 2 - DESCRIPTION : INSTRUMENTS AND CONTROLS).
- The control units must never in any event be used for any other than their intended purposes (e.g. climbing onto or down from the platform, portmanteau, etc.).
- In the case of scissors-type platforms, it is forbidden to use the platform without the guardrails in place.
- Suspending a load under the basket or on any part of the lifting apparatus is strictly forbidden.
- The operator must not climb into or get down from the basket unless it is at ground level (with the lifting system folded).
- The platform must not be fitted with any accessory increasing the machine's wind profile.
- Do not use a ladder or any improvised constructions in the basket to reach greater heights.
- Do not climb on the sides of the basket to reach greater heights.

C - ENVIRONMENT

- Comply with site safety regulations.
- The platform can be manoeuvred from the ground: ensure that you forbid access.
- If you have to use the platform in a dark area or at night, make sure it is equipped with working lights.
- The platforms may not be used as cranes or elevators for the permanent transport of people or materials, nor as jacks or supports.
- When operating, ensure that there is no one or anything impeding the platform's progress and operation.
- When raising the platform, ensure that no one or anything impedes the platform's operation and do not perform any inappropriate manoeuvres.



- Do not allow anybody to come near the working area of the platform or pass beneath an elevated load. To do this, mark your operating area with warning signs.
- Travelling on a longitudinal slope :
 - Ensure that you adapt the platform's travelling speed by controlling the speed with the travelling manipulator.
- Take into account the platform's dimensions and its load before trying to negotiate a narrow or low passageway.
- Never move onto a loading platform without having first checked :
 - That it is suitably positioned and made fast.
 - That the unit to which it is connected (wagon, lorry, etc.) will not shift.
 - That this platform is prescribed for the size and the total weight of the platform.
 - That the slope is not greater than the platform's maximum authorised slope.
- Never move onto a foot bridge, floor or freight lift, without being certain that they are prescribed for the weight and size of the platform to be loaded and without having checked that they are in sound working order.
- Be careful in the area of loading bays, trenches, scaffolding, soft land and manholes.
- Ensure that the ground or floor under the wheels and/or the stabilizers is stable and firm before raising the basket. If necessary, add sufficient wedging under the stabilizers.
- Do not attempt any operations outside the platform's capabilities.
- Ensure that the materials on the platform (pipes, cables, containers, etc ...) cannot slip off and fall. Do not heap up these materials to the point where you have to step over them.



If the basket must remain stationary over a structure for a long period, there is a risk that the basket will rest on this structure because of the oil cooling in the cylinders or a minor leak in the cylinder locking system.

To eliminate this risk :

- ***Regularly check the distance between the basket and the structure and re-adjust if necessary.***
- ***If possible use the platform at an oil temperature as close as possible to ambient temperature.***

- In the case of work near aerial lines, ensure that the safety distance is sufficient between the working area of the platform and the aerial line.



You must consult your local electrical agency. You could be electrocuted or seriously injured if you operate or park the platform too close to power cables.



*If the platform comes into contact with electric wires, press the Emergency Stop button.
If you can, jump from the basket without simultaneously being in contact with the basket and the ground.
If not, call for help, warn people not to touch the basket and to switch off the power supply to the wires or have it switched off.*



If the wind is in excess of 45Km/h, do not make any movements putting the platform's stability at risk.

D - VISIBILITY

- Maintain permanently good visibility throughout the route. To increase your visibility, you can move forwards with the pendular arm slightly raised (pay attention to the risk of falls in the basket from knocking into a low doorway, overhead electric wires, travelling cranes, highway bridges, tracks or any obstacle in the area in front of the platform). In reverse, look directly behind you. In any case, avoid reversing over long distances.
- If visibility of your road is inadequate, ask someone to help, standing outside the area in which the platform will be moving, and make sure you always have a good view of this person.



E - STARTING THE PLATFORM

PLATFORMS WITH IC ENGINES

SAFETY NOTICE

- Never try to start the platform by pushing or towing it. Such operation may cause severe damage to the transmission. In case of necessity, towing requires the platform to be set for free-wheeling (see : 3 - MAINTENANCE).
- If using an emergency battery for start-up, use a battery with the same characteristics and respect battery polarity when connecting it. Connect at first the positive terminals before the negative terminals.



*Failure to respect polarity between batteries can cause serious damage to the electrical circuit. The electrolyte in the battery may produce an explosive gas. Avoid flames and generation of sparks close to the batteries.
Never disconnect a battery while it is charging.*

INSTRUCTIONS

- Check the closing and locking of the hood(s).
 - Turn the ignition key to notch I to switch on the electrical power, which automatically starts the pre-heating system (all the bars must be displayed), the message "OK" is displayed.
 - Check that everything is operating correctly by ensuring that no fault pages are displayed on the screen and no warning about the fuel level (a pump icon is present on the screen) (see : 2 - DESCRIPTION : INSTRUMENTS AND CONTROLS).
 - Turn the ignition key to notch II to start.
 - Release the ignition key and let the engine run at tick-over speed.
- NB : In very cold weather (see: 2 - DESCRIPTION : INSTRUMENTS AND CONTROLS).
- Do not engage the starter motor for more than 15 seconds and carry out the preheating for 10 seconds between unsuccessful attempts.
 - Check all control instruments when the I.C. engine is warm and at regular intervals during use, so as to quickly detect any faults and to be able to correct them without any delay.
 - If any faults are displayed on the screen, stop the engine and immediately take the necessary measures.

ELECTRIC PLATFORMS

SAFETY NOTICE

- Do not use the platform if the battery is discharged to the point that movements are slowed down. In certain cases, the platform may stop (see : 3 - MAINTENANCE : EVERY DAY OR EVERY 5 HOURS FOR OPERATION, for the minimum permissible charge level).

INSTRUCTIONS

- Set the battery cut-out to the ON position.
- Check the closing and locking of the hood(s).
- Turn the ignition key to the basket position.
- Check that everything is operating correctly by ensuring that no error messages are displayed on the screen and that the machine maintenance light is not flashing (see : 2 - DESCRIPTION : INSTRUMENTS AND CONTROLS).

NB: For machines not fitted with a display or a maintenance warning light, faults can be identified from the light directly on the variable speed drive unit (to access: open the cowl on the control size, remove the casing from the variable speed drive and see whether the light is flashing).



- If any error messages are constantly displayed or the machine maintenance light is flashing, return the key to the neutral position.
- Set the battery cut-off to the OFF position.
- Immediately take the necessary measures.

F - DRIVING THE PLATFORM

SAFETY NOTICE



Operators should be aware of the risks connected with using the platform, notably:

- *Risk of losing control.*
- *Risk of losing lateral and frontal stability of the platform.*

The operator must remain in control of the platform.

- Do not carry out operations which exceed the capacities of your platform.
- Familiarise yourself with the platform on the terrain where it will be used.
- Ensure that the brakes work efficiently when stopping a travelling movement, taking into account the braking distances.
- Drive smoothly at an appropriate speed for the operating conditions (land configuration, load in the basket).
- take extreme care if manoeuvring the platform with the basket in the high position. Ensure you have adequate visibility.
- Take bends slowly.
- In all circumstances make sure you are in control of your speed.
- Travel slowly on damp, slippery or uneven terrain or on truck ramps.
- Always remember that the hydraulic form of steering is very sensitive to movements.
- Never leave the I.C. engine on when the platform is unattended.
- Look where you are going and always make sure you have good visibility along the route.
- Drive round obstacles.
- Never drive on the edge of a ditch or steep slope.
- Whatever your travelling speed, you must reduce the speed as much as possible before stopping.

INSTRUCTIONS

- When moving the platform a long distance, always travel with the arms folded or the scissors in the low position.
- Engage the appropriate gear (see : 2 - DESCRIPTION : INSTRUMENTS AND CONTROLS).



G - STOPPING THE PLATFORM

SAFETY NOTICE

- Never leave the ignition key in the platform during the operator's absence.
- Make sure that the platform is not stopped in any position that will interfere with the traffic flow and at less than one meter from the track of a railway.
- In the event of prolonged parking on a site, protect the platform from bad weather, particularly from frost (check the level of antifreeze), close and lock all the platform accesses (cows...).)

INSTRUCTIONS

PLATFORMS WITH IC ENGINES

- Before stopping the platform after a long working period, leave the I.C. engine idling for a few moments, to allow the coolant liquid and oil to lower the temperature of the I.C. engine and transmission



Do not forget this precaution, in the event of frequent stops or warm stalling of the I.C. engine, or else the temperature of certain parts will rise significantly due to the stopping of the cooling system, with the risk of badly damaging such parts.

- Stop the I.C. engine with the ignition switch.
- Remove the ignition key.
- Check that all the accesses on the platform are closed and locked (cows...).

ELECTRIC PLATFORMS

- Remove the ground/platform control selection key.
- Check that all the accesses on the platform are closed and locked (cows...).
- Set the battery cut-out to the OFF position (ELECTRIC PLATFORM).



INSTRUCTIONS FOR WELDING AND BLOW TORCH WORK ON THE EXTERNAL STRUCTURE



Ensure that there are no hydraulic or electrolyte leaks on the platform.



When welding, work in the opposite direction from the control console to avoid sparks damaging it .

Any welding and cutting (blow torch) work from the basket on a building's metallic structures requires the following precautions to be taken:

A - WITH ELECTRIC WELDING EQUIPMENT

- It is essential that the machine has a discharge braid connecting the platform's chassis to the ground.
- It is also essential that the external structure to be welded is connected to the earth. If the above conditions are observed, the platform can, in this case, be in contact with the structure or the elements to be welded without damaging the electronic components.
- The power supply to the welding equipment must be via an earthed socket and any extension required just also be earthed.
- In all cases, ensure that there are no electrical arcs in the basket or on the platform (contact between the brazing rod or the torch and the welding equipment's earth). To ensure this, at any time the welding equipment's earth must not be positioned on the platform's basket but instead only as close as possible to the element to be welded.
- Switch off the welding equipment before disconnecting the earth clamp from the element or elements to be welded.

B - WITH A BLOW TORCH

- Attach the blow torch's bottles to the basket's handrails.
- instructions for welding and blow torch work on the external structure
- Do not set the blow torch down on the lip of the basket while it is still operating or point it towards the control console or its power cables.



PLATFORM MAINTENANCE INSTRUCTIONS

GENERAL INSTRUCTIONS

- Ensure the area is sufficiently ventilated before starting the platform.
- Wear clothes suitable for the maintenance of the platform, avoid wearing jewellery and loose clothes. Tie and protect your hair, if necessary.
- Stop the engine before conducting any work on the platform, remove the ignition key and disconnect the "Minus" battery terminal.
- Set the battery cut-out to the OFF position (ELECTRIC PLATFORM).
- Read the operator's manual carefully.
- Carry out all repairs immediately, even if the repairs concerned are minor.
- Repair all leaks immediately, even if the leak concerned is minor.
- Make sure that the disposal of process materials and of spare parts is carried out in total safety and in a ecological way.
- Be careful of the risk of burning and splashing (exhaust, radiator, I.C. engine, etc.).

MAINTENANCE

- Perform the periodic service (see : 3 - MAINTENANCE) to keep your platform in good working conditions. Failure to perform the periodic service may cancel the contractual guarantee.

LUBRICANT AND FUEL LEVELS

- Use the recommended lubricants (never use contaminated lubricants).
- Do not fill the fuel tank when the I.C. engine is running.
- Only fill up the fuel tank in areas specified for this purpose.
- Do not fill the fuel tank to the maximum level.
- Do not smoke or approach the platform with a flame, when the fuel tank is open or is being filled.

LEVEL OF ELECTROLYTE IN THE BATTERY

- Check the level of the battery or batteries.



When doing this, ensure you take all the safety precautions (See: 3 - MAINTENANCE).

HYDRAULIC

- Make any repairs and fix any leaks, including minor ones, immediately.
- Do not attempt to loosen unions, hoses or any hydraulic component with the circuit under pressure.



BALANCING VALVE : *It is dangerous to change the setting and remove the balancing valves or safety valves which may be fitted to your platform cylinders. These operations must only be performed by approved personnel (consult your dealer).*



Ensure that all consumables and replacement parts are disposed of safely, in an environmentally friendly manner.

ELECTRICITY

- Do not drop metallic items on the battery (between the “Plus” and “Minus terminals”).
- Disconnect the battery or batteries before working on the electrical circuit.
- The electrical box must only be opened by authorized personnel.

WELDING ON THE ACCESS PLATFORM

- Disconnect the battery or batteries before welding on the platform.
- When carrying out electric welding work on the platform, connect the negative cable from the equipment directly to the part being welded, so as to avoid high tension current passing through the alternator or the live ring.
- If the platform is equipped with an electronic control unit, disconnect this before starting to weld, to avoid the risk of causing irreparable damage to electronic components.

WASHING THE PLATFORM

- Clean the platform or at least the area concerned before any intervention.
- Remember to close and lock all accesses to the platform (cowls...).
- When cleaning with a pressure washer, avoid the articulation joints, and the electrical components and connections.
- If necessary, protect components likely to be damaged, and in particular the electrical components (variable speed drive, charger) and connections and the injection pump from penetration by water, steam or cleaning products.
- Dry the electrical components.
- Clean the platform of any fuel, oil or grease trace.
- Grease the shafts.

FOR ANY INTERVENTION OTHER THAN REGULAR MAINTENANCE, CONSULT YOUR DEALER.



IF THE PLATFORM IS NOT TO BE USED FOR A LONG TIME

INTRODUCTION

The following recommendations are intended to prevent the platform from being damaged when it is withdrawn from service for an extended period.

For these operations, we recommend the use of a MANITOU protective product, reference 603726. Instructions for using the product are given on the packaging.



Procedures to follow if the platform is not to be used for a long time and for starting it up afterwards must be performed by your dealership.

PREPARING THE PLATFORM

- Clean the platform thoroughly.
- Check and repair any leakage of fuel, oil, water or air.
- Replace or repair any worn or damaged parts.
- Wash the painted surfaces of the platform in clear and cold water and wipe them.
- Touch up the paintwork if necessary.
- Shut down the platform (see : OPERATING INSTRUCTIONS UNLADEN AND LADEN).
- Make sure the cylinder rods are all in retracted position.
- Release the pressure in the hydraulic circuits.

PROTECTING THE I.C. ENGINE

- Fill the tank with fuel (see : 3 - MAINTENANCE).
- Empty and replace the cooling liquid (see : 3 - MAINTENANCE).
- Leave the I.C. engine running at idling speed for a few minutes, then switch off.
- Replace the I.C. engine oil and oil filter (see : 3 - MAINTENANCE).
- Add the protective product to the engine oil.
- Run the I.C. engine for a short time so that the oil and cooling liquid circulate inside.
- Disconnect the battery and store it in a safe place away from the cold, after charging it to a maximum.
- Remove the injectors and spray the protective product into each cylinder for two seconds with the piston in low neutral position.
- Turn the crankshaft once slowly and refit the injectors (see I.C. engine REPAIR MANUAL).
- Remove the intake hose from the manifold or turbocharger and spray the protective product into the manifold or turbocharger.
- Cap the intake manifold hole with waterproof adhesive tape.
- Remove the exhaust pipe and spray the protective product into the exhaust manifold.
- Refit the exhaust pipe and block the outlet with waterproof adhesive tape..
- NOTE : The spray time is noted on the product packaging.
- Open the filler plug, spray the protective product around the rocker arm shaft and refit the filler plug.
- Cap the fuel tank using waterproof adhesive tape.
- Remove the drive belts and store them in a safe place.
- Disconnect the engine cut-off solenoid on the injection pump and carefully insulate the connection.



CHARGING THE BATTERIES

- In the case of electric platforms, in order to preserve the batteries' life and their capacity, check them periodically and keep the charge level constant (see : 3 - MAINTENANCE).

PROTECTING THE PLATFORM

- Protect cylinder rods which will not be retracted, from corrosion.
 - Wrap the tyres.
- NOTE : If the platform is to be stored outdoors, cover it with a waterproof tarpaulin.

BRINGING THE PLATFORM BACK INTO SERVICE

- Remove the waterproof adhesive tape from all the holes.
- Refit the intake hose.
- Reconnect the engine cut-off solenoid.
- Refit and reconnect the battery.
- Remove the protection from the cylinder rods.
- Perform the daily service (see : 3 - MAINTENANCE)
- Empty and replace the fuel and replace the fuel filter (see : 3 - MAINTENANCE).
- Refit and set the tension in the drive belts (see : 3 - MAINTENANCE).
- Turn the I.C. engine using the starter, to allow the oil pressure to rise.
- Lubricate the platform completely (see : 3 - MAINTENANCE : TABLEAU D'ENTRETIEN).




Make sure the area is adequately ventilated before starting up the platform.

- Start up the platform, following the safety instructions and regulations (see : OPERATING INSTRUCTIONS).
- Carry out all the lifting system's hydraulic movements right up to the limit switches for each cilinder.



SAFETY DECALS





DESCRIPTION

- 1 - WHITE ARROW
- 2 - BLACK ARROW
- 3 - LOAD PER WHEEL
- 4 - MANUAL CONTROL PROCEDURE
- 5 - MANUAL CONTROL PROCEDURE FOR ROTATING JIB
- 6 - BLADE SAFETY INSTRUCTIONS
- 7 - WASHING RECOMMENDATIONS
- 8 - ANCHORING HOOK
- 9 - BASKET INSTRUCTIONS / LOAD CAPACITY
- 10 - REPLACING THE BATTERIES
- 11 - BATTERY CUT-OFF / DANGER BATTERY CHARGE / 230 VOLT 16 A SOCKET
- 12 - DANGER KEEP AWAY
- 13 - RISK OF SHEARING
- 14 - RISK OF CRUSHING
- 15 - POSITION OF THE PLATFORM KEY


MEANING

1. WHITE ARROW

This indicates the direction of travelling when moving forwards.



When the turret assembly, the arms assembly and the basket make a 180° rotation with respect to the chassis, the travelling controls are reversed. Identify the forward direction by looking at the arrows on the chassis and on the basket control console.




2. BLACK ARROW

This indicates the direction of travelling when reversing.



Same: white arrow




NB: As on the basket console and the chassis, the white arrows indicate forward travelling and the black arrows reverse travelling.

3. LOAD PER WHEEL

This indicates the maximum load on one wheel and the load the wheel will exert on the ground (see 2 - DESCRIPTION: CHARACTERISTICS for the piercing value).



Before using the platform, identify the type of ground and find out its ability to resist being pierced.



NB: The weight must be visible on the platform.

4. MANUAL CONTROL PROCEDURE


This describes the procedure for: lowering or turning the basket, turning the turret and directing the wheels using the pump and the manual controls.

PROCEDURE :

Thumbnail 1 : Unscrew and remove the protective cover over the indexed controls.

Thumbnail 2 : Pick up the lever.

Thumbnail 3 : Position the lever on the manual pump.





Association of the two operations ② + ① :

Depending on the movements desired:

② - Push in and lock the wheel (left-hand bubble) OR pull out and lock the wheel (right-hand bubble) + ① - Pump.

This enables you to perform:

Top left column downwards,

The five movements below:

- Raise the basket and the pendular arm
- Raise the pendular arm (the basket stays horizontal)
- Extend the telescope
- Raise the upper arm
- Raise the intermediate arms

Top right column downwards,

The five movements below:

- Lower the basket and the pendular arm
- Lower the pendular arm (the basket stays horizontal)
- Retract the telescope
- Lower the upper arm
- Lower the intermediate arms

Association of the two operations ③ + ① :

Depending on the movements desired:

③ - Push the wheel in and hold it in this position (left-hand bubble) OR pull the wheel out and hold it in this position (right-hand bubble) + ① - Pump.

This enables you to perform:

Top left column downwards,

The three movements below:

- Basket rotation right
- Point wheels left
- Turret rotation right

Top right column downwards,

The three movements below:

- Basket rotation left
- Point wheels right
- Turret rotation left

Thumbnail 4: Screw on the protective cover for the indexed controls.

5. MANUAL CONTROL PROCEDURE FOR ROTATING JIB (3D PLATFORMS)


This describes the procedure for turning the pendular arm / basket assembly.

PROCEDURE (see sticker N° 4):

Thumbnail 1 : Unscrew and remove the protective cover over the indexed controls.

Thumbnail 2 : Pick up the lever.

Thumbnail 3 : Position the lever on the manual pump.



Association of the two operations ② + ① :

Depending on the movements desired:

② - Push in and lock the wheel (left-hand bubble) OR pull out and lock the wheel (right-hand bubble) + ① - Pump.

This enables you to perform:

Left-hand column,

The movements below:

- Rotation of the basket assembly and pendular arm to the right


Right-hand column,

The movements below:

- Rotation of the basket assembly and pendular arm to the left


6. **BLADE SAFETY INSTRUCTIONS**

Take note of the safety and operating instructions before you start the platform.



7. **WASHING RECOMMENDATIONS**

It is strictly forbidden to direct a pressure washer's nozzle over the control buttons and electrical components.



8. **ANCHORING HOOK**

This sticker indicates the anchoring points for tying down the platform on the flatbed of a truck.




9. **BASKET INSTRUCTIONS / LOAD CAPACITY**

This describes three points:

- The platform's capabilities for use indoors and out of doors.
- The risk of electric shock.
- An invitation to read the instructions for more detailed information on the safety instructions.


NB: Each platform has its own capabilities: please refer to this sticker for your particular platform.






10. REPLACING THE BATTERIES

This indicates that the weight of the new batteries must be greater than or equal to those you are replacing. If this instruction is not observed, the platform's stability will be compromised.



11 A. BATTERY CUT-OFF

This indicates the position of the battery cut-out and its effect:
Position OFF: le courant ne passe pas.
Position ON: le courant passe.



11 B. DANGER BATTERY CHARGE

This describes three points:

- The risk of explosion when batteries are charging.
- Batteries must be charged outside or in a well-ventilated area.
- The risk of explosion during charging, due to a spark, a flame or a short-circuit.



Do not smoke near the access platform when the batteries are being charged.

11 c. 230VOLT 16A SOCKET

This informs you that to charge the batteries you must connect the charger to a socket supplying 230 Volts with an intensity of 16 Amps.



The socket must be protected by a differential circuit breaker with 30mA protection.


12. DANGER : KEEP AWAY

It is strictly forbidden to cross under or park under the structure (arms, scissors, pendular arm, basket, etc.) and in the area over which the platform operates.



13. RISK OF SHEARING

It is strictly forbidden to place your fingers, or any other part of the body, in the parts of the lifting system (arms, scissors, pendular arm, etc.): risk of being cut or crushed.




14. RISK OF CRUSHING

It is strictly forbidden to park in this area when the platform is moving (rotating, etc.). The elements on which the stickers are affixed could collide with you, with the risk of crushing you.



15. POSITION OF THE PLATFORM KEY

The spare keys for the access platform (ignition key, control selector key, key for locking casings...) are stored in the place provided for the purpose.





2 - DESCRIPTION





CONTENTS

<i>PLATFORM IDENTIFICATION</i>	<i>2 - 4</i>
<i>CHARACTERISTICS</i>	<i>2 - 5</i>
<i>DIMENSIONS 120 AETJ L</i>	<i>2 - 10</i>
<i>DIMENSIONS 150 AETJ C</i>	<i>2 - 12</i>
<i>DIMENSIONS 150 AETJ L</i>	<i>2 - 14</i>
<i>DIMENSIONS 170 AETJ L</i>	<i>2 - 16</i>
<i>PLATFORM OPERATION</i>	<i>2 - 19</i>
<i>CONTROL INSTRUMENTATION</i>	<i>2 - 22</i>
<i>GROUND BACKUP AND MAINTENANCE STATION</i>	<i>2 - 26</i>
<i>BASKET COMMAND AND CONTROL STATION</i>	<i>2 - 33</i>
<i>USE OF THE PLATFORM</i>	<i>2 - 37</i>
<i>RESCUE PROCEDURE</i>	<i>2 - 41</i>



PLATFORM IDENTIFICATION

It is our policy to improve our products constantly. Certain modifications may be made to our range of platforms without our being required to advise our customers.

On any order for replacement parts or for any technical information, please always specify:

NB: To be able to provide all these numbers more easily, we recommend that you write them down in the locations provided for this on receipt of the platform.


PLATFORM MANUFACTURER'S PLATE (FIG. A)

- Type _____
- Serial No. _____
- Year of manufacture _____

A																													
MANITOU																													
MANITOU BF 44158 ANCENIS CEDEX FRANCE																													
MODEL																													
Serial no.																													
Year of manufacture																													
Empty weight	kg																												
Power	kW																												
Voltage	VDC																												
	<table border="1"> <thead> <tr> <th>INSIDE</th> <th>OUTSIDE</th> </tr> </thead> <tbody> <tr> <td colspan="2">Max. load</td> </tr> <tr> <td>kg</td> <td>kg</td> </tr> <tr> <td colspan="2">Max. no of persons</td> </tr> <tr> <td colspan="2">Fittings</td> </tr> <tr> <td>kg</td> <td>kg</td> </tr> <tr> <td colspan="2">Manual forces</td> </tr> <tr> <td>daN</td> <td>daN</td> </tr> <tr> <td colspan="2">Max. tilt</td> </tr> <tr> <td>°</td> <td>°</td> </tr> <tr> <td colspan="2">Max. wind speed</td> </tr> <tr> <td>m/s</td> <td>m/s</td> </tr> <tr> <td colspan="2">Ext electrical source</td> </tr> <tr> <td colspan="2">Volts</td> </tr> </tbody> </table>	INSIDE	OUTSIDE	Max. load		kg	kg	Max. no of persons		Fittings		kg	kg	Manual forces		daN	daN	Max. tilt		°	°	Max. wind speed		m/s	m/s	Ext electrical source		Volts	
INSIDE	OUTSIDE																												
Max. load																													
kg	kg																												
Max. no of persons																													
Fittings																													
kg	kg																												
Manual forces																													
daN	daN																												
Max. tilt																													
°	°																												
Max. wind speed																													
m/s	m/s																												
Ext electrical source																													
Volts																													
N° 678438																													

LOCATION OF THE MANUFACTURER'S PLATE (FIG. B)

The manufacturer's plate is fastened to the rear of the chassis on the left-hand side.



CHARACTERISTICS

ELECTRIC PUMP

- Power supply	48 V
- Power	3,6 KW
- Cubic capacity	4,8 cm ³
- Pressure	200 bar

ELECTRICAL WHEELS MOTORS


- Type	T 17 - 2 KW
--------	-------------

ELECTRICAL CIRCUIT

- Battery	48 V - 300 Ah (150AETJC - 150AETJL - 170AETJL)
- Charger	48 V - 240 Ah (120AETJL) 45 Ah (Mono)

FUSES

- Main card (Base control box):	5 A (1 Fig A) and 15 A (2 Fig A)
- Power (Contactor plate):	325 A (3 Fig B)
- Electric pump (Variable speed drive plate):	100 A (4 Fig C)





120 AETJ L

SPECIFICATIONS

- Use	Indoors and Outdoors
- Capacity	200 Kg including 2 people
- Maximum authorized wind speed	45 Km/h
- Control system	Hydro-electric
- Turret rotation	355°
- Working speed	0,6 km/h
- Speed in transport	5 km/h
- Working height	11950 mm
- Height of floor	9950 mm
- Max. offset	6870 mm
- Weight of the access platform	
• Unloaded	5050 kg
• In nominal load	5250 kg
- Number of speed	2
- Negotiable slope	30%
- Max. permissible tilt	5% or 3°

TYRES

DIMENSIONS	TYPE	LOAD PER TYRE UNLADEN		WITH MAX. LOAD + DOFF-CENTRING ON 1 WHEEL FRONT / REAR	CONTACT SURFACE OF 1 WHEEL WITH GROUND	STAMPING
		FRONT	REAR			
600 X 190	TYRE	2370 KG	2680 KG	2800 KG	- CM ²	- DAN/CM ²

Wheel nut tightening torque ; front wheels

34 daNm

Wheel nut tightening torque ; rear wheels

22 daNm



150 AETJ C

SPECIFICATIONS

- Use	Indoors and Outdoors
- Capacity	200 Kg including 2 people
- Maximum authorized wind speed	45 Km/h
- Control system	Hydro-electric
- Turret rotation	355°
- Working speed	0,6 km/h
- Speed in transport	5 km/h
- Working height	14990 mm
- Height of floor	12990 mm
- Max. offset	7600 mm
- Weight of the access platform	
• Unloaded	6700 kg
• In nominal load	6900 kg
- Number of speed	2
- Negotiable slope	23%
- Max. permissible tilt	5% or 3°

TYRES

DIMENSIONS	TYPE	LOAD PER TYRE UNLADEN		WITH MAX. LOAD + OFF-CENTRING ON 1 WHEEL FRONT / REAR	CONTACT SURFACE OF 1 WHEEL WITH GROUND	STAMPING
		FRONT	REAR			
600 X 190	TYRE	2930 KG	3770 KG	3600 KG	- CM ²	- DAN/CM ²

Wheel nut tightening torque ; front wheels

34 daNm

Wheel nut tightening torque ; rear wheels

22 daNm



150 AETJ L

SPECIFICATIONS

- Use	Indoors and Outdoors
- Capacity	230 Kg including 2 people
- Maximum authorized wind speed	45 Km/h
- Control system	Hydro-electric
- Turret rotation	355°
- Working speed	0,6 km/h
- Speed in transport	5 km/h
- Working height	15280 mm
- Height of floor	13280 mm
- Max. offset	7810 mm
- Weight of the access platform	
• Unloaded	5910 kg
• In nominal load	6140 kg
- Number of speed	2
- Negotiable slope	26%
- Max. permissible tilt	5% or 3°

TYRES

DIMENSIONS	TYPE	LOAD PER TYRE UNLADEN		WITH MAX. LOAD + DOFF-CENTRING ON 1 WHEEL FRONT / REAR	CONTACT SURFACE OF 1 WHEEL WITH GROUND	STAMPING
		FRONT	REAR			
600 X 190	TYRE	1240 KG	1715 KG	3600 KG	283 CM ²	12,5 DAN/CM ²

Wheel nut tightening torque ; front wheels

34 daNm

Wheel nut tightening torque ; rear wheels

22 daNm



170 AETJ L

SPECIFICATIONS

- Use	Indoors and Outdoors
- Capacity	200 Kg including 2 people
- Maximum authorized wind speed	45 Km/h
- Control system	Hydro-electric
- Turret rotation	355°
- Working speed	0,6 km/h
- Speed in transport	5 km/h
- Working height	16910 mm
- Height of floor	14910 mm
- Max. offset	9430 mm
- Weight of the access platform	
• Unloaded	6910 kg
• In nominal load	7110 kg
- Number of speed	2
- Negotiable slope	22%
- Max. permissible tilt	5% or 3°

TYRES

DIMENSIONS	TYPE	LOAD PER TYRE UNLADEN		WITH MAX. LOAD + OFF-CENTRING ON 1 WHEEL FRONT / REAR	CONTACT SURFACE OF 1 WHEEL WITH GROUND	STAMPING
		FRONT	REAR			
600 X 190	TYRE	1520 KG	1935 KG	4200 KG	- CM ²	- DAN/CM ²

Wheel nut tightening torque ; front wheels

34 daNm



Wheel nut tightening torque ; rear wheels

22 daNm




DIMENSIONS 120AETJ L

A	5520
A1	3930
B	2000
C	1995
C1	2210
D	1500
E	153
F	2640
G	1870
H	3960
I	4520







G1	2350	H1	9950
G2	3105	H2	8795
G3	6370	H3	4775
G4	5640	H4	545




DIMENSIONS 150AETJ C

A	6050
A1	4400
B	2000
C	1965
C1	2080
D	1500
E	143
F	2640
G	1870
H	3960
I	4820








G1	2665	H1	12985
G2	3425	H2	11835
G3	7105	H3	7165
G4	6300	H4	235




DIMENSIONS 150AETJ L

A	5960
A1	4400
B	2000
C	1970
C1	2080
D	1750
E	143
F	2880
G	1970
H	4270
I	4890







G1	2660	H1	13275
G2	3420	H2	12120
G3	7310	H3	7165
G4	6500	H4	205




DIMENSIONS 170AETJ L

A	6840
A1	5120
B	2000
C	1970
C1	2040
D	1750
E	143
F	2890
G	2005
H	4300
I	5600





G1	2840	H1	14910
G2	3600	H2	13750
G3	8930	H3	7160
G4	8130	H4	270







PLATFORM OPERATION

DESCRIPTION

- This machine is a mobile platform for lifting people. It consists of a work platform fastened to the end of a pendular arm, itself fastened to the end of a telescopic arm and the whole assembly is fastened to an articulated arm structure.
- MANITOU lifting platforms are solely for use for bringing people, and their tools and supplies (within the authorised weight limit, please refer to the paragraph "SPECIFICATIONS"), to a desired working height, to reach hard-to-access locations over installations and buildings.
- The lifting platform is equipped with a control station in the basket. From this, the operator can drive or move the machine forwards or backwards. He can raise or lower all the arms, extend or retract the telescopic arm and turn the turret or the basket right or left. The basket, arms and turret assembly can rotate within an angle of 355 degrees, non-continuously, to the right and the left of its folded position.
- The lifting platform is also equipped with a ground backup and maintenance station which can control all lifting functions except travelling. The base controls are only to be used in an emergency to bring the operator back to ground level if he is incapable of doing this himself.
- The ground backup and maintenance station and the basket control station must be checked by the operator every day to ensure that they work properly.



The characteristics, safety instructions and rescue procedure stickers are affixed to the machine. The operator must take note of these and understand their contents. To avoid any risk of misinterpreting the pictograms, please refer to the Paragraph "SAFETY STICKERS" in Chapter 1 – SAFETY ADVICE AND INSTRUCTIONS.

- The lifting platform's movements are powered by a hydraulic pump, operated by a battery-powered electric motor. The hydraulic components are controlled by electro-valves actuated by contactors and the manipulator.
- The base or basket console's controls are via changeover contactors and are either in "Run" or "Stop" mode.
- **The base console is equipped with a so-called "Dead Man's" push button. This must be pressed in at the same time a contactor is switched over. Releasing it stops the movement.**
- The lifting platform is a two-wheel drive machine driven by an electric motor on each wheel. The drive wheels have spring-operated, hydraulically released brakes. These brakes tighten automatically as soon as the travelling manipulator is returned to the neutral position.
- The lifting platform can lift up to the limit of its capacities (see "SPECIFICATIONS" in this Chapter). Having a maximum capacity load or less in the basket will still enable you to move in any position, provided that the machine on ground with a slope of no more than 3°.

GENERAL

- In the following pages, you will find all the information required for using the machine, including the platform's operating, driving, parking, loading and transport instructions.



SAFETY

SLOPE



When the access platform has reached the maximum authorised inclination (see chapter : CHARACTERISTICS), the LED 23* on the basket console flashes regularly. Furthermore, the beeper 33* in the basket also sounds intermittently.

All "AGGRAVATING" movements - raising the arms, extending the telescope movements are prohibited for safety reasons .



To restore these functions, only perform "disaggravating" movements :

- Return to safe position by retracting the telescope and lowering the arms: then position the platform on a more horizontal surface so that you can raise the arms and extend the telescope.




OVERLOAD

When the access platform has reached the maximum authorised weight (see chapter : CHARACTERISTICS) in the basket. The overload LED at the ground backup and maintenance station 3* and the basket console 22* flash regularly. The beeper 33* in the basket sounds constantly. All movements are prohibited for safety reasons.




To restore these functions :

- Lighten the basket by removing the item(s) causing the overload,
OR,
- Ask someone at ground level to lower the basket under manual control (see "RESCUE PROCEDURE" in this Chapter and "SAFETY STICKERS" in Chapter 1 "SAFETY ADVICE AND INSTRUCTIONS").



* : the above references are the same as those used in the description of these components in the following pages.






NB : INCOHERENCE of OVERLOAD SENSORS, LOW ARM position and TELESCOPE extension / retraction.

This memo is to inform you that the slope and overload LEDs may, in certain situations, be activated intermittently and the beeper may sound constantly, for reasons other than excessive slope position or overloaded basket.

*For your safety, the access platform is equipped with two **overload** sensors. If only one sensor is activated, the access platform is blocked, the **display** (see Ref. 7 on the following pages) **displays fault code "F02004"**. At the same time :*



on the basket console :

- Beeper 33* sounds constantly.
- LED 22* flashes in sets of 5 flashes every 2 seconds.

on the base console :

- LED 3* flashes regularly.
- LED 4* flashes in sets of 5 flashes every 2 seconds.

*For your safety, the access platform is equipped with two sensors for the **low arm** position and two for **telescope extension / retraction**. If only one sensor is activated in either of these functions, the **display** (see Ref. 7 on the next page) **displays fault code "F02005"**. At the same time :*

on the basket console :

- Beeper 33* remains silent.
- LED 22* flashes in sets of 5 flashes every 2 seconds.

on the base console :

- LED 4* flashes in sets of 5 flashes every 2 seconds.









*If the fault continues to be displayed, immobilise the platform and make the necessary repairs.
Consult your dealer.*

* : the above references are the same as those used in the description of these components in the following pages.

CONTROL INSTRUMENTATION

A - GROUND BACKUP AND MAINTENANCE STATION








A - GROUND BACKUP AND MAINTENANCE STATION

- 1 - EMERGENCY STOP
- 2 - KEY-OPERATED CONTROL SELECTOR SWITCH AT GROUND LEVEL OR IN THE BASKET
- 3 - OVERLOAD LAMP
- 4 - "MAINTENANCE MACHINE" LAMP
- 5 - "STATE OF CHARGE OF THE BATTERY" LAMP
- 6 - "DEAD MAN" BUTTON
- 7 - BATTERY CHARGE INDICATOR AND THE HORAMETER
- 8 - PLATFORM ROTATION CONTACTOR
- 9 - RAISE AND LOWER CONTACTOR OF THE EXTENSION ARM
- 10 - ROTATION CONTACTOR FOR ROTATED JIB (OPTION 3D)
- 11 - TELESCOPE OUTPUTS AND INPUTS CONTACTOR
- 12 - RAISE AND LOWER CONTACTOR OF THE SUPERIOR ARM
- 13 - RAISE AND LOWER CONTACTOR OF THE INFERIOR ARM
- 14 - TURRET ROTATION CONTACTOR
- 15 - INCLINATION CONTACTOR OF THE PLATFORM
- 16 - BATTERY SWITCH
- 17 - FLASHING LIGHT (OPTION)
- 18 - SLOPE SENSOR
- 19 - SOUND ALARM HORN
- 20 - BLOCKAGE OF THE TURRET ROTATION

CONTROL INSTRUMENTATION

B - BASKET COMMAND AND CONTROL STATION





B - BASKET COMMAND AND CONTROL STATION

- 21 - EMERGENCY STOP**
- 22 - OVERLOAD LAMP AND VARIATOR DEFECTS**
- 23 - SLOPE LAMP**
- 24 - SOUND ALARM HORN**
- 25 - CONTROL SWITCH**
- 26 - CONTACTOR OF SELECTION OF ROTATION**
- 27 - PLATFORM INCLINATION CONTACTOR**
- 28 - EXTENSION ARM LIFTING / LOWERING CONTACTOR**
- 29 - TELESCOPE OUTPUTS / INPUTS CONTACTOR**
- 30 - SUPERIOR ARM LIFTING / RAISING CONTACTOR**
- 31 - INFERIOR ARM LIFTING / RAISING CONTACTOR**
- 32 - TRAVELLING CONTACTOR**
- 33 - ALARM BUZZER**
- 34 - SAFETY HARNESS ATTACHMENT POINTS**
- 35 - CONSOLE PROTECTIVE COVER**

NB: The terms RIGHT-LEFT-FRONT-REAR apply to a user on the nacelle platform in the transportation position and looking straight ahead.

GROUND BACKUP AND MAINTENANCE STATION

1 - EMERGENCY STOP

This red mushroom-head switch cuts off all the machine's movements in the event of any anomalies or danger.


- Press the knob to stop the machine's movements.
- Turn the knob a quarter of a turn to the right to restore the power (the switch automatically returns to its initial position).



This command takes priority in all circumstances, even when control is switched to the access platform.




If the Emergency Stop is pressed, movements may stop very abruptly.



2 - KEY-OPERATED CONTROL SELECTOR SWITCH AT GROUND LEVEL OR IN THE BASKET


This 3-position BASKET / BASE control station, with the Stop position in the centre, powers the basket control console when it is set in the PLATFORM position. When the selector is in the BASE position, power to the console in the BASKET is cut off and only the base controls can be used.

- A** : - Functions are controlled from the basket command and control station.
- B** : - Neutral position : the platform controls are idle (remove the key in this position)
- C** : - Functions are controlled from the ground backup and maintenance station.



3 - OVERLOAD LAMP


If the basket is overloaded, the LED flashes intermittently (See : ACCESS PLATFORM OPERATION- SAFETY INSTRUCTIONS).



4 - "MAINTENANCE MACHINE" LAMP

- THIS LAMP HAS TWO FUNCTIONS:

- ① This lamp is controlled by a timer, which brings it on every 50 hours worked (Counting of the number of hours the hydraulic pump has operated).
When the lamp is on (fixed LED), this mean that the machine must be serviced (see chapter "MAINTENANCE TABLE").
NB: To deactivate this light, see 7 "Battery charge and timer indicator lights".
- ② In the event of a fault, the number of flashes indicates the type of fault detected by the variator:
 - 1 flash : Variator parameter defect
 - 2 flashes : Command activated before the use
 - 3 flashes : Variator in short-circuit
 - 4 flashes : Defect contactors of power
 - 5 flashes : Sensor synchronisation fault
 - 6 flashes : Accelerator, control switch, potentiometer or wire of speed sensor
 - 7 flashes : Battery discharged
 - 8 flashes : Variator temperature over high
 - 9 flashes : Bobbin contactor in short-circuit
 - 12 flashes : Defect bus connection.



*If the LED flashes permanently, stop the access platform.
Consult your dealer*

5 - "STATE OF CHARGE OF THE BATTERY" LAMP

The lamp changes of colors according to the state of the battery charge:

The red led:

- The charger is on the initial phase of charge.

The yellow led:

- The battery is charged at 80% of charge.

The green led:

- The battery is charged.



BATTERY AUTONOMY

- The following functions will be switched off when you reach 20% of load, in working or transport speed position, at the ground backup and maintenance control station or basket command and control station :

- Raise intermediate arms
- Raise upper arm
- Extend telescope

6 - "DEAD MAN" BUTTON

As a safety measure, this button must be held down constantly to activate the various lifting and rotation functions.





7 - BATTERY CHARGE INDICATOR AND THE HORAMETER

A - BATTERY CHARGE INDICATOR


· BATTERY CHARGED

- All the bars are displayed (dark).

· BATTERY DISCHARGED

- Only two bars are still displayed, meaning that you must proceed to recharge the batteries (See the Chapter "MAINTENANCE INTERVALS").

NB: You must not drop below a battery charge level of 20%; otherwise the batteries can deteriorate rapidly.



The following 2 timers are displayed on startup, but only the counter with the "T" symbol is on during normal operation :

B - DAILY HORAMETRE INDICATOR


It indicates the total number of hours for all the movements made and can be reset to zero.

C - PUMP AND TRACTION HORAMETRE INDICATOR

It indicates the total number of hours for all the movements made

D - FAULT DISPLAY

If the machine breaks down, a fault number is displayed (it will be stored in memory and can be analysed) and the "machine maintenance" light 4 comes on (flashing after faults have occurred).







If the fault continues to be displayed, immobilise the platform and make the necessary repairs.

NB: For the descriptions and frequencies of the faults detected, see this machine's REPAIRS MANUAL.



Consult your dealer.







RESETTING THE DAILY HORAMETRE TIMER TO ZERO

Proceed as follows:

- The platform must be in transport position (arms and telescope completely folded),
- The platform must not be sloping,
- The platform must be in "Ground backup and maintenance station" position, using selector 2 "key-operated control selector at ground level or in the basket " and wait for the initialisation "Beep".
- Press 6, the "dead man button" and at the same time the two contactors : 9 "contactor for raising and lowering the pendular arm" and 15 "basket tilt contactor", until the counter is reset to zero.

NB: This operation should be done during the few seconds following restoration of power to the electrical circuit.




RESET THE TIMER TO ZERO EVERY 50 HOURS OF OPERATION


This must be done after performing the maintenance described in the Chapter: MAINTENANCE "EVERY 50 HOURS OF OPERATION".

Proceed as follows:

- The platform must be in transport position (arms and telescope completely folded),
- The platform must not be sloping,
- The platform must be in "Ground backup and maintenance station" position, using selector 2 "key-operated control selector at ground level or in the basket " and wait for the initialisation "Beep".
- Simultaneously press the "Dead Man's" button 6 and contactors No. 12 ("upper arm raising and lowering contactor") and 13 ("lower arm raising and lowering contactor") until the MACHINE MAINTENANCE light 4 goes out (the timer is reset to zero).



NB: This operation should be done during the few seconds following restoration of power to the electrical circuit.



8 - PLATFORM ROTATION CONTACTOR


- This contactor is used to rotate the platform.

RIGHT ROTATION

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 8 to the right.

LEFT ROTATION

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 8 to the left.



9 - RAISE AND LOWER CONTACTOR OF THE EXTENSION ARM

- This contactor is used to raise or lower the extension arm.

LIFTING OF THE EXTENSION ARM

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 9 upwards.

LOWERING OF THE EXTENSION ARM

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 9 downwards.

10 - ROTATION CONTACTOR FOR ROTATED JIB (OPTION 3D)


- This contactor enables you to rotate the pendular arm.

RIGHT ROTATION

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 10 to the right.

LEFT ROTATION

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 10 to the left.



11 - TELESCOPE OUTPUTS AND INPUTS CONTACTOR

- This contactor enables you to extend and retract the telescope.

TELESCOPE EXTENSION

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 11 to the left.

TELESCOPE RETRACTION

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 11 to the right.

12 - RAISE AND LOWER CONTACTOR OF THE SUPERIOR ARM

- This contactor is used to raise or lower the superior arm.

LIFTING OF THE SUPERIOR ARM

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 12 upwards.

LOWERING OF THE SUPERIOR ARM

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 12 downwards.

13 - RAISE AND LOWER CONTACTOR OF THE INFERIOR ARM


- This contactor is used to raise and lower the inferior arm.

LIFTING OF THE SUPERIOR ARM

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 13 upwards.

LOWERING OF THE INFERIOR ARM

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 13 downwards.



14 - TURRET ROTATION CONTACTOR

- This contactor is used to rotate the turret.

RIGHT ROTATION

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 14 to the right.

LEFT ROTATION

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 14 to the left.

15 - INCLINATION CONTACTOR OF THE PLATFORM


- This contactor is used for the correction of the horizontality of the platform or the complete re-folding of the platform in the transportation position.

CORRECTION OF THE PLATFORM UPWARD

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 15 upwards.

CORRECTION OF THE PLATFORM DOWNWARD

- Place the base/basket switch in the base position, keep the "dead man" button pushed and push the switch 15 downwards.



16 - BATTERY SWITCH


The battery cut-out switch is located on the chassis on the ground backup and maintenance station side.

IN THE ON POSITION

Turn the handle a quarter of a turn: current flows.

IN THE OFF POSITION

Turn the handle a quarter of a turn: current stops flowing.




Always set the battery cut-out to the OFF position when you are not using the platform.

The sound alarm (see 19 - SOUND ALARM HORN) will come on if the battery cut-out is left ON when the batteries are being charged.

17 - FLASHING LIGHT (OPTION)


- The flashing alarm lamp turns on automatically when the platform is travelling, or if a movement is carried out (*Lifting, rotation,...*).



18 - SLOPE SENSOR

- This sensor checks the platform's inclination. When the platform reaches the maximum authorised inclination (See the Chapter: CHARACTERISTICS), the buzzer (33) sounds intermittently and all the "AGGRAVATING" movements – raising the arms, extending the telescope – are blocked. The LED (23) on the platform is lit.

NB: SLOPE TEST; set the platform on a flat surface in base control position (see 2 – KEY-OPERATED CONTACTOR). Press the sensor "PRESS TO TEST", the buzzer should sound and the LED light up.




If the buzzer does not sound and the LED does not light, immobilise the platform and make the necessary repairs.

19 - SOUND ALARM HORN

This sound alarm horn (fixed to the turret above the ground backup and maintenance station box) is activated by pressing button 24.



The alarm will be activated if the BATTERY CUT-OUT is left on the ON position when charging the batteries (see 16 – BATTERY CUT-OUT).




20 - BLOCKAGE OF THE TURRET ROTATION

- Put the spindle in the space foreseen for this effect.
 - This spindle is used to lock the turret rotation when she is in position.
 - She must be used when the access platform is transported by truck or by another transport (train ...).



Do not forget to remove its during the use of the access platform.



NB: Releasing the pin; you may have to rotate the turret right or left to free the pin to extract it from its location.

BASKET COMMAND AND CONTROL STATION

21 - EMERGENCY STOP

This red mushroom-head switch cuts off all the machine's movements in the event of any anomalies or danger.


- Press the knob to stop the machine's movements.
- Turn the knob a quarter of a turn to the right to restore the power (the switch automatically returns to its initial position).



In any case, this control has priority, unless movements are controlled by the ground backup and maintenance station.




If the Emergency Stop is pressed, movements may stop very abruptly.



22 - OVERLOAD LAMP AND VARIATOR DEFECTS


- THIS LAMP HAS TWO FUNCTIONS :

- ① If the basket is overloaded, the LED flashes intermittently (See : ACCESS PLATFORM OPERATION – SAFETY INSTRUCTIONS).
- ② In case of fault, the number of flashes indicates the type of fault detected by the variator (See: 4 - Lamp "MAINTENANCE MACHINE" p 2-17).




23 - SLOPE LAMP

When the access platform has reached the maximum authorised slope the LED flashes intermittently See : ACCESS PLATFORM OPERATION – SAFETY INSTRUCTIONS).



24 - SOUND ALARM HORN

- When button 24 is pressed, it activates the sound alarm horn 19 located on the turret.




25 - CONTROL SWITCH

NB: This control switch is progressive control, and gives a very high approach accuracy. Its use should be smooth and free of jerks.



SAFETY TRIGGER

- This trigger (item A) of control switch 25 must be continually pushed in to perform movements from the operating of the access platform.



26 - CONTACTOR OF SELECTION OF ROTATION

This contactor (26) has three positions. Switch it over to the movements you desire and then use the manipulator (25).

PLATFORM ROTATION

- Switch the contactor 26 to the left (position I).
- Incline to the right or to the left the control switch 25 to orientate on the right or on the left respectively.

TURRET ROTATION




- Switch the contactor 26 to vertical (position II).
- Incline to the right or to the left the control switch 25 to orientate on the right or on the left respectively.

ROTATION OF ROTATED JIB (3D PLATFORMS)

- Switch the contactor 26 to the right (position III).
- Incline to the right or to the left the contactor 25 in order to rotate on the right or on the left respectively.



Before you make any rotation manoeuvres, check that there is enough space between the platform or the turret and the various walls and installations.





27 - 28 - 29 - 30 - 31 - 32 - MOVEMENT SELECTION CONTACTOR

27 PLATFORM INCLINATION CONTACTOR

- Select the movement by pressing button 27; the movement remains selected while the LED is lit (8 seconds).
- Push (forward) or pull (backward) the switch control 25 to raise or lower.

NB : The basket can only be tilted when the machine is in transport position.
(see USING THE ACCESS PLATFORM).

28 EXTENSION ARM LIFTING / LOWERING CONTACTOR

- Select the movement by pressing button 28; the movement remains selected while the LED is lit (8 seconds).
- Push (forward) or pull (backward) the switch control 25 to raise or lower.

29 TELESCOPE OUTPUTS / INPUTS CONTACTOR

- Select the movement by pressing button 29; the movement remains selected while the LED is lit (8 seconds).
- Push (forward) or pull (backward) the switch control 25 to go out or go back.

30 SUPERIOR ARM LIFTING / RAISING CONTACTOR


- Select the movement by pressing button 30; the movement remains selected while the LED is lit (8 seconds).
- Push (forward) or pull (backward) the switch control 25 to raise or lower.

31 INFERIOR ARM LIFTING / RAISING CONTACTOR

- Select the movement by pressing button 31; the movement remains selected while the LED is lit (8 seconds).
- Push (forward) or pull (backward) the switch control 25 to raise or lower.

32 TRAVELLING CONTACTOR

- Select the movement by pressing button 32 briefly (See NB for button B) ; the movement stays selected as long as the LED is on (8 seconds).
- Push (forward) or pull (backward) the switch control 25 to advance or retract.



DIRECTION:


- TO STEER TO THE LEFT OR THE RIGHT WITHOUT MOVING IN TRAVELLING:

- Select the direction by pressing button B on the manipulator 25 (constant pressure) to the right or the left of the button to go respectively right or left.

- TO STEER TO THE LEFT OR THE RIGHT WITH TRAVELLING:

- Select the direction by pressing button B on the manipulator 25 (constant pressure) to the right or the left of the button to go respectively right or left.
- Push the manipulator (25) forwards or pull it backwards respectively to go forward or reverse while steering the wheels.

NB : Pressing button B on the manipulator briefly also selects the travelling movement, the movement stays selected as long as the LED (same as contactor 32) is on (8 seconds).






33 - ALARM BUZZER

- This buzzer sounds when the machine is in either of the critical situations below:


- **Case 1 ; INTERMITTENCE :** (See : ACCESS PLATFORM OPERATION - SAFETY INSTRUCTIONS).
- **Case 2 ; CONTINUOUS :** (See : ACCESS PLATFORM OPERATION - SAFETY INSTRUCTIONS).



34 - SAFETY HARNESS ATTACHMENT POINTS

- These attachment points should be used to fasten the harnesses when operators are in the basket.

NB: See Chapter 1 - "SAFETY ADVICE AND INSTRUCTIONS".




35 - CONSOLE PROTECTIVE COVER




Once opened, this retractable casing protects the control panel from bad weather and flying particles from various types of work.



After each day of platform use or during work where there is a risk of flying particles, close the protective casing.



USE OF THE PLATFORM



DISPLACEMENT TRANSPORT MODE / WORKING MODE



Before moving and using the machine, remove the turret blocking system 1 (see Fig. A).

The contactor 2 (Fig. B) should be in the position A (transfer of commands on the desk of the platform).

The access platform has two modes of displacements: the transport mode (Fig. D) and the working mode (Fig. E) (Direction of advance (Fig. C).

- **Transport mode:** the access platform arms are in low position. This mode is used to move at high speed and go beyond the slope of the machine (Fig. D) (See chapter : CHARACTERISTICS).

- **Working mode:** One or many arms of the access platform are lifted or the telescope is gone out. In this mode, the travelling are made with a small speed, the safeties for the slope and the overload are activated. (Fig. E).



No movement over terrain with a slope greater than the authorised inclination (see the Chapter: CHARACTERISTICS) or with deformations likely to make the platform overturn or with the jib higher than horizontal when the machine is on an unstable surface.




Before driving the platform, ensure that the basket control station is correctly over the drive wheels; if it is over the steering wheels, the controls will be reversed compared to the machine's direction of travel.

TRANSPORT / WORK SPEED MODE LIMITATION

The pendular arm can raise and lower in transport speed mode with the telescope retracted.

Details on changing from transport speed to working speed:

Extend the telescope less than 2cm and the lower arms to the stop (raised < 5cm); over either of these values, the platform switches to working speed mode.



INSTALLATION ON THE WORK SITE AND LIFTING

The platform has been designed to work on a flat, horizontal surface: it is important to clear the area where the platform will operate.



Make sure you are familiar with the instrumentation at the ground backup and maintenance station and the basket control station, described in the pages above, particularly the warnings indicating the risks linked to performing certain movements.

- Move the access platform into its working area.
- If necessary, load the equipment and the supplies, distribute the load uniformly (arrange it in a way so as not to inconvenience the user and avoid any items falling off).
- Climb into the access platform.



It is strongly recommended to wear a safety helmet and harness.



During manoeuvres of the access platform (raise, rotate, etc. ...), keep looking above and about you. Watch out in particular for electric cables and any other objects that may be located in the volume in which the access platform moving.

LOWERING

When the work has been completed : lower the telescope and the arm, returning the machine to the transportation position.



Watch out carefully for people on the ground when lowering the access platform

STOPPING OF THE ACCESS PLATFORM

When the platform is not being used, switch off the power supply by setting the key-operated contactor to the Neutral position (see 2 – KEY-OPERATED CONTACTOR).

At the end of the day: recharge the batteries if necessary (see the Chapter "MAINTENANCE INTERVALS").



Always set the battery cut-out to the OFF position when you are not using the platform.


LOADING AND UNLOADING OF THE ACCESS PLATFORM



Check that the safety instructions associated with the flatbed are being observed before loading the access platform, and make sure that the truck driver is informed about the dimensional characteristics and the weight of the access platform. (see chapter: CHARACTERISTICS).

During the loading on a flatbed, the access platform should be in transportation position: - Counterweight opposite the ramp (counterweight above the access platform's steerable wheels) (See 1 - INSTRUCTIONS AND SAFETY measures ; chapter on SAFETY STICKERS, references 1 and 2).

- Upper arm on its end stop
- Lower and intermediate arm in the low position
- Telescope retracted
- The pendular arm can be raised so that it does not touch the ground but we do not advise you to make any travelling movements with the basket raised too high: keep this in the lowest possible position when manoeuvring (risk of impacts or falls: see 1 – SAFETY ADVICE AND INSTRUCTIONS; Chapter DRIVING INSTRUCTIONS).
- Lock the turret.



Make sure that the dimensions and load capacity of the flatbed are adequate for transporting the access platform. Also check the permissible ground contact pressure of the flatbed in relation to the access platform.

LOADING

- Chock the wheels of the flatbed item 1 (Fig A).
- Secure the loading ramps to the flatbed so as to make the smallest possible angle for loading the access platform.



NB : The machine is represented with a reduce space required (platform is completely folded up) (Fig A).

ACCESS PLATFORM RETRACTION PROCEDURE

- Rotate to the left until the basket reaches its stop.
- Raise the upper arm.
- Switch on the basket tilt movement to retract the basket under the upper arm.
- Lower the upper arm, taking care not to bump the basket on the ground.
- Switch on the basket tilt movement again to retract the basket as far as possible under the upper arm.
- Switch on turret rotation to the right so that the overall width does not exceed the width of the chassis.

ANCHORING THE ACCESS PLATFORM

- Place wheel chocks on the flatbed in front and behind each tyre of the access platform. Item 2 (Fig A).
- Also place chocks on the inside and outside of each tyre. Item 3 (Fig A).
- Anchor the access platform to the flatbed using ropes of suitable strength. Tie the ropes at the front and the rear, passing them through the lifting eyes on the access platform Item 4 (Fig A) Item 5 (Fig B).





UNLOADING



*Never **drive down** from a truck **in forward gear** (counterweight to the front above the steerable wheels), the low adhesion of the rear wheels would reduce braking power.*



Ensure that you adapt the platform's travelling speed by controlling the speed with the travelling manipulator.

RESCUE PROCEDURE

This paragraph describes the procedures to be followed and the controls to be used if a problem arises (the platform breaks down or someone is trapped in the basket) while the platform is operating.

When taking charge of the machine and at regular intervals afterwards, the operator (and anyone else whose duties are centred on activities in contact with the machine) should read and fully understand this procedure.

INDISPOSITION OF THE USER

If the user should be taken ill or become incapable of manoeuvring the machine, the person on the ground can take over the access platform controls using the ground backup and maintenance station.

Follow the instructions below:

- Switch the key-operated contactor 1 (Fig. A) on the ground backup and maintenance console to position C, to take over control of the access platform's movements.
- Lower the access platform.



Pay attention to any structure or obstacle located below the access platform.

IN THE EVENT OF ACCIDENT OR BREAKDOWN

Evacuate anyone in the basket.

If an accident or a breakdown occurs, which renders the electrical boxes unusable, the machine is provided with systems for performing all the movements manually.

- Open the right cowling of the turret.
- To execute one of the platform's movements, you must index the knob by pulling or pushing it (Fig. B) OR push or pull on the pusher (Fig. C) for one of the distributor's elements (Diagram E Page 2 - 26) and pump simultaneously (Fig. D).








Diagram of the functions of the distributor:



PROCEDURE OF FREE WHEELING



The platform may only be towed a short distance and only by a machine with significant braking performance, in order to hold it: the two machines must be connected by a tow bar.



- To set the platform to free wheel, it must not be subject to any travelling stresses from slopes. The wheels must be able to turn freely.
- If possible, raise the platform to free the drive wheels in order to facilitate the operation.
- Loosen bolt 1 (Fig. F) on each wheel 22 mm from the edge, up to the resistance point, without forcing it (2 daNm) : see (Fig. G).
- The machine can be towed as a trailer.



*Warning : do not loosen screws more than 22 mm ; risk of rupture and major damage to the reducer.
If in doubt, contact your dealer.*

RE-INSTALLATION

- Turn the wheel gently from left to right to reset the gear while retightening the screws (1) (Fig. F). Pay attention to the torque when tightening (15 daNm).







3 - MAINTENANCE





TABLE OF CONTENTS

<i>MANITOU ORIGINAL SPARE PARTS AND EQUIPMENT</i>	<i>3 - 5</i>
<i>FILTER ELEMENT</i>	<i>3 - 7</i>
<i>LUBRICANTS</i>	<i>3 - 7</i>
<i>MAINTENANCE SCHEDULE</i>	<i>3 - 9</i>
<i>A - EVERY DAY OR EVERY 5 HOURS OF OPERATION</i>	<i>3 - 10</i>
<i>B - EVERY 50 HOURS OF OPERATION</i>	<i>3 - 13</i>
<i>C - EVERY 100 HOURS OF OPERATION</i>	<i>3 - 15</i>
<i>D - OCCASIONAL MAINTENANCE</i>	<i>3 - 20</i>





MANITOU ORIGINAL SPARE PARTS AND EQUIPMENT

**OUR ACCESS PLATFORMS MUST BE MAINTAINED
WITH ORIGINAL MANITOU PARTS.**

IF YOU USE PARTS WHICH ARE NOT ORIGINAL MANITOU PARTS,

YOU RISK

- legally - to be held responsible in the event of an accident.
- Causing technical functional failure or reducing the platform's life.

**THE USE OF COUNTERFEIT PARTS OR COMPONENTS NOT APPROVED BY THE MANUFACTURER,
MEANS YOU LOSE THE BENEFIT OF THE CONTRACTUAL GUARANTEE.**

BY USING ORIGINAL MANITOU PARTS FOR MAINTENANCE OPERATIONS,

**YOU BENEFIT
EXPERTISE**

THROUGH ITS NETWORK, MANITOU PROVIDES THE USER WITH,

- know-how and competence.
- the guarantee of high-quality work.
- original replacement components.
- help with preventive maintenance.
- efficient help with diagnosis.
- improvements due to experience feedback.
- operator training.
- Only the MANITOU network is familiar with the details of the platform design and is therefore technically the best qualified to provide maintenance services.

**ORIGINAL REPLACEMENT PARTS ARE DISTRIBUTED EXCLUSIVELY
BY MANITOU AND ITS DEALER NETWORK.**

The dealer network list is available on manitou web site www.manitou.com



FILTER ELEMENT



1

DESCRIPTION	REFERENCE	REPLACE
1 - Oil filter cartridge hydraulic intake	599004	100 H

LUBRICANTS

DEVICES TO BE LUBRICATED	CAPACITY	RECOMMENDATION	PACK	REFERENCE
HYDRAULIC OIL TANK	12 Litres	HYDRAULIC MANITOU ISO 46 oil	20 L. 55 L. 209 L.	582 297 546 108 546 109
WHEEL REDUCING (EACH)	0.8 Litres	SHELL SPIRAX A80W90	2 L. 20 L 55 L	499 237 546 330 546 221
TURRET GEAR MOTOR REDUCTION BRAKE	1.5 Litres			
GENERAL GREASING GREASING OF TURRET CROWN WHEEL BEARING TRACKS		MANITOU grease High Performance	400 g cartridge	479 330
LUBRICATION OF THE TEETH CROWN TURRET		SHELL MALLEUS GL 205 oil	Aerosol	545 834





MAINTENANCE SCHEDULE

A = ADJUST	N = CLEAN
C = CHECK	P = PURGE
Ch = LOAD	R = REPLACE
D = DESCALE	V = EMPTY
G = GREASE	

After the first 50 hours	Day or 5 hours	50 hours or 6 months*	100 hours or 1 year*	200 hours or 2 years*
--------------------------	----------------	-----------------------	----------------------	-----------------------

TRANSMISSION

Rear wheel reducer oil			V/R	◀◀	PAGE 3-16
------------------------	--	--	-----	----	-----------

TYRES

Tightening wheelnuts			C	◀◀	◀◀	3-14
Condition of wheels and tyres				C**	◀◀	

HYDRAULICS

Hydraulic return oil filter cartridge	R	◀◀	◀◀	R	◀◀	3-17
Auxiliary hydraulic oil filter cartridge						
Hydraulic oil level		C	◀◀	◀◀	◀◀	3-11
Hydraulic oil				V/R	◀◀	3-17
Hydraulic circuit strainer				N	◀◀	3-17
Backup pump			C	◀◀	◀◀	3-14
Turret motor brake reducer				V/R	◀◀	3-18

ELECTRICITY

Battery charge		C	◀◀	◀◀	◀◀	3-10
Batteries		Ch	◀◀	◀◀	◀◀	3-10
Density of battery electrolyte		C	◀◀	◀◀	◀◀	3-11
Battery electrolyte level		C	◀◀	◀◀	◀◀	3-11
Tightening electric power cables			C	◀◀	◀◀	3-14
Replace the batteries						3-19
Battery boxes		V	◀◀	◀◀	◀◀	3-12
State of manipulator boots		C	◀◀	◀◀	◀◀	3-12

FRAME

Access platform slew ring				G	◀◀	3-15
Tightening screws on the turret slew ring	C	◀◀	◀◀	C	◀◀	3-15
Shafts			G	◀◀	◀◀	3-13
Steering pivots						
Steering bearings						
Scissor system slide rails						

LIFTING FRAME

Arm			G	◀◀	◀◀	3-13
Mast						
Locking the telescope						
Basket overload and rotation						
Tightening turret rotation motor bolts				C	◀◀	3-18

SAFETY COMPONENTS

Arm position sensors		C**	◀◀	◀◀	◀◀	3-12
Slope sensor		C**	◀◀	◀◀	◀◀	3-12
Overload sensor			C**	◀◀	◀◀	3-18
Machine stickers		C**	◀◀	◀◀	◀◀	3-12

*: At the first period reached

** : Consult your dealer

A - EVERY DAY OR EVERY 5 HOURS OF OPERATION

A1 - BATTERY CHARGE


CHECK

The platform has 5 hours of effective autonomy, with batteries fully charged.

When all the sections of the dial 1 (Fig. A1/1) are black, this indicates that the batteries are fully charged.

- When using the access platform, the number of sections shows the battery charge status.
- Where there are two sections 2 (Fig. A1/1) still black, this means that the batteries are 80 % discharged and it is time to recharge them.

NB: You must not drop below a battery charge level of 20%, otherwise the batteries will rapidly deteriorate irreversibly.



A2 - BATTERIES

LOAD


- The access platform is fitted with an electric charger, located under the cowling of the wheels motors.


USE THE CHARGER.



Re-charge the battery in a ventilated area, in which it is strictly forbidden to smoke, in order to avoid the risk of explosion.

- Remove the batteries covers 1 (Fig. A2/1) and leave it open all the time while loading.
- Switch off the power to the access platform using the battery switch 2 (Fig. A2/2).
- Do not place any metal objects on the batteries (risk of short circuit).
- Do not remove the cell caps.
- Do not re-charge the batteries if the temperature of the electrolyte is over 40°C. Allow it to cool first.
- Connect extension 3 to the mains (Fig. A2/1).






The alarm will be activated if the BATTERY CUT-OUT is left on the ON position when charging the batteries.

NB : 10 hours of charge are required for a battery which is 70% to 80% discharged.

When the batteries are charged:

- Disconnect the power lead 3 (Fig. A2/1).
- Close the battery covers 1 (Fig. A2/1).
- Re-connect the power supply of the access platform with a battery switch 2 (Fig. A2/2).

NB : The charger was adjusted in the factory for the cable with which it was supplied. If this cable is replaced, be sure to use the same cable section and the same cable length.






A3 - HYDRAULIC OIL LEVEL

CHECK

- Open the left hand cowling.
- Set the platform in transport position
- The oil level should reach the middle of signal light 1 (Fig. A3).
- If necessary, add oil (see chapter "LUBRICANTS") via the fill orifice A (Fig. A3).




A4 - BATTERY ELECTROLYTE LEVEL

CHECK

Check the level of the electrolyte in each cell of the batteries.

- Remove the battery lids 1 (Fig. A4/1).
- Lift the cap 2 (Fig. A4/2) on each battery terminal.
- The level must be above the filter (see level in 3 (Fig. A4/2)).
- If necessary, top up with clean distilled water, stored in a glass carboy.
- Replace the caps 2 (Fig. A4/2).



A5 - DENSITY OF BATTERY ELECTROLYTE


CHECK

The specific gravity of the electrolyte with temperature, but a minimum of 1270 to 16° C must be maintained.

In the hatched part of figure (Fig. A5), the batteries are charged normally. Above this area, the batteries need to be re-charged.


The specific gravity must not vary by 0,025 units from one battery cell any other.

- Check the electrolyte specific gravity in each element of the batteries with a acetometer.
- Never check after filling with distilled water.
- Re-charge the batteries, and wait for 1 hour before checking the specific gravity.



Handling and servicing a battery can be dangerous, take the following precautions

- *Wear protective goggles*
- *Handle batteries horizontally*
- *Never smoke or work near a naked flame*
- *Work in a well-ventilated area*
- *In the event of electrolyte being spilled onto the skin or splashed in the eyes, rinse thoroughly with cold water for 15 minutes and call a doctor.*




A6 - BATTERY BOXES

EMPTY

- Stop the access platform.
- Remove the battery caps.
- Make sure there is water in the battery boxes by connecting the aspirator bulb 1 (Fig. A6/1) to pipe 2 (Fig. A6/2)
- Drain the water from the boxes.



*Water in the boxes will lead to deterioration of the batteries, causing a short-circuit at positive and negative terminals.
Dispose of dirty water (electrolyte + water) by ecological means.*



A7 - STATE OF MANIPULATOR BOOTS


CHECK

- Stop the access platform.

For this operation, climb into the basket.

- Check the condition of the rubber manipulator boots 1 (Fig. A7/1), by moving them as if to perform a movement.

The boots must not be cracked or fissured, with the risk of infiltration of water which would prevent the machine from working properly.



A8 - ARM POSITION SENSORS


CHECK

For this operation, fold the arms into transport position.

- Perform a travelling movement at transport speed.
- Raise the arms or extend the telescope.
- Move forwards.
- The platform must move into working speed.



*In the event of a malfunction, prohibit use of the platform.
Consult your dealer.*



A9 - SLOPE SENSOR

CHECK

Sensor test (See : 2 - DESCRIPTION : CONTROL SYSTEM INSTRUMENTS, item 19)



*In the event of malfunction, prohibit use of the platform.
Consult your dealer.*

A10 - MACHINE STICKERS

CHECK

(CONSULT YOUR DEALER)


B - EVERY 50 HOURS OF OPERATION

B1 - SHAFTS


GREASE

- Clean, then grease the following points with grease, (See chapter: "LUBRICANTS") and remove the excess.



Legend: Axle stop



Hub



Penstock



B2 - TIGHTENING WHEELNUTS

CHECK

- Check the wheel nuts are tight (Fig. B2).

Not applying this recommendation can lead to the deterioration and breaking of the wheel bolts, as well as the deformation of the wheels.

B2	
TIGHTENING TORQUE OF THE WHEEL NUTS	
FRONT WHEELS	34 daN/m ± 15%
REAR WHEELS	22 daN/m ± 10%

B3 - BACKUP PUMP

CHECK

- Stop the platform.

- Make sure the backup pump is working properly (See : 2 - DESCRIPTION : RESCUE PROCEDURE)

- Perform an arm lowering movement (e.g....)




You must not use the platform under any circumstances if the pump is not working.

B4- TIGHTENING ELECTRIC POWER CABLES

CHECK

Make sure that the circuit connectors and various components of the power bundle are tight (Fig. B4/1).





C - EVERY 100 HOURS OF OPERATION


C1 - ACCESS PLATFORM SLEW RING

GREASE

- The greasing of the bearing tracks and lubrication of the teeth should be carried out every 100 hours of operation, and also before and after a long period of non use.
- Grease to be required: (see chapter: LUBRICANTS)
- Remove the inner cowling of turret 1 (Fig. C1/1).
- Reach to the 2 grease points (Fig. C1/2) and grease with abundance the crown by orienting the turret (access to the represented grease points Fig. C1/2).



- Spray the lubricant on the crown wheels 3 and pinion 4 (Fig. C1/3).
- Lubricant to be required: (see chapter : LUBRICANTS)



C2 - TIGHTENING SCREWS ON THE TURRET SLEW RING

CHECK

- Screw 5 (Fig. C1/2) tightness must be checked after 50 hours of operation at the latest. It must then be checked every 100 hours of operation.
- The theoretical tightening torque of the screws is $27,5 \text{ daNm} \pm 10\%$.
- $1 \text{ daN} = 1 \text{ Kg}$.

C3 - REAR WHEEL REDUCER OIL

EMPTY - REPLACE

- Place the access platform on an horizontal ground in transportation position and the warm oil of the reducers.
- Raise the back of the platform (using the two sling eyeholes (Fig. C3/1) or any other means of lifting).



Slide a wooden wedge between the chassis and the ground to ensure operational safety.

- Remove the rear wheels (Fig. C3/2)







A wheel weighs from 40 Kg to 53 Kg.

- Place the cap of drainage 2 (Fig. C3/3) lower.
- Place a tray under the cap of drainage and unscrew it.
- Remove the cap 3 (Fig. C3/3) in order to facilitate the drainage.
- Let the oil to drain completely.



Dispose of the waste oil ecologically.

- Put the orifice 2 in the position like in the (Fig. C3/4).
- Fill up with oil (see chapter : LUBRICANTS) by the orifice 3 (Fig. C3/4).
- The level is good when the oil reaches the orifice 2 (Fig. C3/4).
- Replace and screw the caps 2 and 3 (Fig. C3/4).
- Remount the wheels (See B2 for the tightening torque).



C4 - HYDRAULIC OIL

EMPTY - REPLACE


C5 - HYDRAULIC CIRCUIT STRAINER

CLEAN

- Place the access platform on an horizontal ground in transportation position.
- Open the left hand cowling.


DRAIN OF THE OIL

- Place a tray underneath the drain orifice 1 (Fig. C4/1) and unscrew this.
- Remove the fill cap 3 (Fig. C4/3) in order to facilitate the drainage process..



CLEANING THE STRAINER

- Unscrew the strainer 2 (Fig. C4/2) into the tray, clean its with a compressed air.
- Screw the strainer into position.




FILLING WITH OIL

- Replace and screw the drain plug 1 (Fig. C4/1).
- Fill up with hydraulic oil via the fill orifice (see chapter "LUBRICANTS") by the fill orifice 3 (Fig. C4/3).
- The oil level should reach the middle level of the indicator 4 (Fig.C4/3)..



Dispose of the waste oil ecologically. Use a very clean funnel and tray and clean the underside of the oil can before filling.




C6 - HYDRAULIC RETURN OIL FILTER CARTRIDGE

REPLACE

- Unscrew the three screws of fixing of the cover 5 (Fig. C4/4).
- Remove the filter cartridge 6 (Fig. C4/4) and replace it by a new one (see chapter "FILTER ELEMENT").

NB : Attention to the assembling sense.

- Retighten the cover 7 (Fig. C4/4) of filter support.
- Tighten the three fastening screws on lid 5 (Fig. C4/4).




C7 - TIGHTENING TURRET ROTATION MOTOR BOLTS

CHECK

Set the platform on a horizontal surface.

- Open the left hand cowling.
- Check the tightness of the nine bolts 1 (Fig. C7/1).
- The tightening torque for the bolts is 8 daN.m \pm 10%.
- 1 daN = 1 Kg



C8 - TURRET MOTOR BRAKE REDUCER

EMPTY - REPLACE

Set the platform on a horizontal surface.

- Remove the turret's left cover.
- Remove the filling-breather cap 2 (Fig. C7/1) to ensure good drainage.
- Mark the drain plug 3 located on the bottom of the reducer unit (Fig. C7/1).
- Place a small receptacle to catch the oil.
- Loosen the drain plug.



Dispose of the oil in an environmentally friendly manner

- Use a syringe to fill the reducer via the filling-breather cap 2 (Fig. C7/1). The oil capacity is 1.3 litres and the level is correct when the breather is full of oil.
- Re-insert the filling-breather cap 2 (Fig. C7/1).

C9 - OVERLOAD SENSOR

CHECK

For this operation, fold the arms into transport position.

- Place a heavier weight than that indicated in the basket (see : 2 - DESCRIPTION : SPECIFICATIONS).
- Telescope extension and arm raising movements must be blocked (the overload signal light is on in the basket, the buzzer sounds constantly in the basket).



*In the event of malfunction, prohibit use of the platform.
Consult your dealer.*



D - OCCASIONAL MAINTENANCE

D1 - BATTERIES

REPLACE

When it is necessary to replace the battery, it is important to use the batteries with same capacity and weight to guarantee the stability of the machine.



A traction battery is heavy (265 Kg), so a mechanical lifting system must be used.

- PRECAUTION : - Maintain the battery in vertical position during the lifting.
- Watch over to remove the slings to avoid the short-circuit.
- Watch over the good positioning of the battery on the access platform.

In the event of the introduction of new batteries, re-charge after 3 to 4 hours of using and that 3 to 5 times.





4 - MAINTENANCE HANDBOOK





MAINTENANCE HANDBOOK

- The maintenance handbook is provided by MANITOU's dealer when the machine is put into service.
- It accompanies the machine throughout the guarantee period and subsequently enables regular monitoring of the maintenance conducted on the machine in accordance with MANITOU's recommendations.
- Maintaining the equipment ensures that it is available for use and its profitability.
- The MANITOU dealer can also propose maintenance programmes specially adapted to a variety of needs, ensuring (through his own expertise and the use of MANITOU original replacement parts the equipment's maximum efficiency.
- We recommend that the maintenance handbook be carefully kept throughout the machine operating life and, in particular, that it be handed over to the future owner if the machine is sold.

50 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

100 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

150 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

200 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP



250 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

300 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

350 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

400 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

450 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

500 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP



550 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

600 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

650 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

700 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

750 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

800 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			



850 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

900 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

950 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

1000 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

1050 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP

1100 HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
REMARKS:			DEALER'S STAMP



HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			



HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			



HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

HOURS	DATE	ACTUAL HOURS	ENGINEER'S SIGNATURE
			DEALER'S STAMP
REMARKS:			

